

TTWG-500-BSEN TUF-TUG WIRE GRAB FALL ARRESTOR SHOCK PACK REPLACEMENT

Materials Supplied

- (1) BSEN Shock Pack
- (1) $\varnothing 5/16"$ x 2-1/2" L Hex head bolt
- (1) $\varnothing 7/16"$ x 2" Spacer sleeve
- (1) $\varnothing 5/16"$ Center locknut



Tools Required

- (1) Small 6" adjustable wrench
- (1) Ratchet wrench with $\varnothing 1/2"$ socket



Procedure

STEP 1

Loosen $\varnothing 5/16"$ x 2-1/2" bolt and nut from lever arm with wrenches



STEP 2

Remove nut and bolt from assembly



STEP 3

Dispose of old shock pack with fasteners



STEP 4

Insert new spacer into replacement shock pack



STEP 5

Reattach to wire grab lever with $\varnothing 5/16"$ nut and bolt



STEP 6

Torque assembly to 15 ft.lbs.



STEP 7

Pivot shock pack to assure that it will rotate freely in assembly and reattach carabiner to end of shock pack

